

**ViewSonic®**  
*See the difference™*



IFPG1 series  
Firmware Update SOP

**ViewSonic®**  
*See the difference™*




## Firmware update by USB

Please note that the format of the USB must be FAT32.


### Method 1:

- 1、Download the file corresponding to the model and unzip it
- 2、Put the 'Upgrade\_3683' folder into the root directory of the USB drive.
- 3、Insert the entire USB into the USB 2.0 port of the machine, power it on, and it will automatically initiate the upgrade process. Once the upgrade is complete, the system will automatically restart.



## Method2 :

- 1、 Put the 'Upgrade\_3683' folder into the root directory of the USB drive.
- 2、 insert the entire USB into the USB 2.0 port of the machine, press the bottom “input+991” into factory mode, select “UPGRADE”, select “UPGRADE ALL”, Once the upgrade is complete, the system will automatically restart.



- You can check version in OSD Setting > About >

